



- NOTES:
- 1) X2 TERMINAL GROUNDED AS STANDARD, REMOVE GROUND IF NOT REQUIRED.
  - 2) RCD: STANDS FOR REMOTE CONTROL DEVICE BY CUSTOMER.
  - 3) [ ] : FOR MULTIFUNCTION TERMINAL NUMBERS.
  - 4) ( ) : FOR ALT. AUX. CONTACT TERMINAL NUMBERS.

-	-	-	-	<p><b>NOTICE</b></p> <p>THIS DRAWING IS THE CONFIDENTIAL PROPERTY OF SPRECHER-SCHUH, INC. and, as such, is subject to recall at any time. The drawing may not be reproduced, used or disclosed for any purpose except as authorized by SPRECHER-SCHUH, INC.</p>	DRAWN BY: GS	<p>FVNR MAGNETIC STARTER W/ SS PILOT DEVICES THREE PHASE</p>	<p><b>sprecher+schuh</b> HOUSTON, TEXAS</p>			
-	-	-	-		CHECKED BY: MB			DWG. NO.	SHEET 1 OF 1	SERIES
-	-	-	-		APPROVED BY: JR			DATE	CAT WS-101-01	100
14	GENERAL REVISIONS	04-23-12	MR		DATE			04-13-09		
REV	CHANGE	DATE	BY							